



Identifying the Parts



How to set/reset the combination




1. Align all the dials to zero that is preset at the factory to open at zero.
2. Press the setting dial (3) firmly down.
3. set your new combination.
4. Once new combination is set, pull the setting dial back to original position to complete setting combination.

When forgot your combination




1. Use spare key to open lock on another side.
2. Insert the searching key (8) into combo slot (5) and turn the dials until the searching key can be pushed to end and the dials can't be turned. You can open the lock now. To reset your new combination simply repeat the reset combination instruction.

各部零件說明



密碼設定



1. 預設出廠密碼為0-0-0-0，請依此密碼開啟鎖具。
2. 設定密碼時請將圖示(3)變號鈕按住並往下推固定住。
3. 旋轉密碼轉盤(4)至預設定號碼。
4. 設定完成後將變號鈕推回原位，即設定完成。再次開鎖時即須以設定之密碼開啟。

密碼遺忘時解救方式



1. 使用鑰匙開啟鎖具。
2. 將探索針插入圖(5)探索孔並轉動號碼轉盤，當號碼正確時探索針能持續往內移動而該轉盤無法轉動。當四個號碼完全正確時探針會完全插入探索孔內，並能打開號碼鎖。重新設定密碼請依照密碼設定部分重新設定。