



Instruction of the assembly:

Plug A compatible with Shimano 8,9&10 speed

Plug B compatible with Shimano 7 & Campagnolo 8 speed

Plug C compatible with Campagnolo 9 speed

Plug D compatible with SRAM/ ESP

You can find the plug marked with A,B,C,D in the plastic joint.